



AUTO POWER ON / OFF
SIMPLY PRESS AND HOLD TO HEAT THE TIP
2 CLICKS TO ADJUST POWER LEVEL
3 CLICKS TO TOGGLE FRONT LED



## **CAUTION! TIP GETS VERY HOT!**

Use extreme care when operating.

Keep away from electrical cords, clothing, flammable liquids, etc.

ALWAYS return to a safe place after use.

Do not touch or damage the heated tip.

Do not disassemble your device.

Do not overcharge your battery.

Never use a damaged battery.

Never leave charging batteries unattended.

Never expose your batteries to extreme temperatures (they should not be stored in temperatures below -4°F/-20°C or exceeding 122°F/50°C).

Do not expose batteries to liquids.

Always charge batteries on a fireproof surface.

Immediately stop use, charge, or storage if the batteries produce an unusual odor, emit heat, change in color or shape, or appear irregular in any way.

Keep away from pets and/or children.



SHARE YOUR EXPERIENCE WITH #CARTAGANG



NEED MORE HELP?
FOCUSV.COM/CONTACT-US

FOCUSV.COM